



---

**1984**

---

**BMW 318i**

---

**Electrical**

---

**Troubleshooting**

---

**Manual**

---

BMW of North America, Inc.  
Montvale, New Jersey

## **FOREWORD**

In the interests of continuing technical development work we reserve the right to modify designs and equipment.

Printed in USA

© Copyright BMW of North America, Inc.  
May 1983

Not to be reproduced wholly or in part  
without written permission of  
BMW of North America, Inc.

PN 89 89 1 000 147

**1984**

---

**BMW 318i**

---

**Electrical**

---

**Troubleshooting**

---

**Manual**

---

**CONTENTS**

---

Index .....	2
How To Use This Manual .....	3
Symbols.....	4
Wire Size Conversion Chart...	5
Systematic Troubleshooting...	6
Diagnostic Connector .....	101
Power Distribution Box .....	102
Fuse Data .....	103
Schematic Diagrams .....	104
Component Charts and Figures.....	201

---

**Index—Alphabetical Listing of Electrical Circuits**

	PAGE		PAGE
Air Conditioning .....	139	Lights (continued)	
Auto-Charging Flashlight .....	131	—Glove Box .....	131
Auxiliary Fan .....	143	—Hazard Warning .....	124
Brake Warning System .....	120	—Headlights (Control) .....	122, 136
Central Locking .....	144	—Headlights (Power) .....	123, 137
Charging System .....	114	—Interior .....	130
Cigar Lighter .....	131	—License .....	127
Diagnostic Connector .....	101	—Rear Marker .....	127
Digital Clock .....	131	—Stoplights .....	129
Fuel Control .....	110	—Tail .....	126
Fuel Delivery .....	109	—Turn .....	124
Fuel Economy Gauge .....	118	—Trunk .....	127
Fuel Gauge .....	117	Power Antenna .....	133
Fuse Data .....	103	Power Distribution .....	104
Gauges .....	117	Power Distribution Box .....	102
Ground Distribution .....	147	Power Mirrors .....	134
Heating .....	139	Power Windows .....	146
Horn .....	129	Radio .....	133
Idle Speed Control .....	112	Rear Defogger .....	132
Ignition .....	109	Seatbelt Warning .....	121
Ignition Key Warning .....	121	Service Interval Indicator .....	119
Indicators .....	116	Speedometer .....	116
Lights		Start .....	108
—Back Up .....	128	Tachometer .....	118
—Dash .....	138	Vacuum Advance .....	113
—Fog .....	122, 136	Warning Indicators .....	117
—Front Park .....	126	Wiper/Washer .....	115
—Front Side Marker .....	126		

The purpose of this manual is to show electrical schematics in a manner that makes electrical troubleshooting easier. Electrical components which work together are shown together on one schematic. The Wiper-Washer schematic, for example, shows all of the electrical components in one diagram. At the top of the page is the fuse (positive) that powers the circuit. The flow of current is shown through all wires, connectors, switches, and motors to ground (negative) at the bottom of the page.

Within the schematic, all switches and sensors are shown "at rest," as though the Ignition Switch were off. For identification, component names are underlined and placed next to or above each component. Notes are included, describing how switches and other components work.

The power distribution schematic shows the current feed through all the connections from the Battery and Alternator to each fuse and the Ignition and Light Switches. If the Power Distribution schematic is combined with any other circuit schematic, a complete picture is made of how that circuit works. The Ground Distribution schematics show how several circuits are connected to common grounds.

All wiring between components is shown exactly as it exists in the vehicle; however, the wiring is not drawn to scale. To aid in understanding electrical operation, wiring inside complicated components has been simplified. The "Solid State" label designates electronic components.

WIRE SIZE CONVERSION CHART	
METRIC (CROSSSECTIONAL AREA IN MM <sup>2</sup> )	AWG (AMERICAN WIRE GAUGE)
.5	20
.75	18
1	16
1.5	14
2	14
2.5	12
4	10
6	8
8	8
16	4
20	4
25	2
32	2

WIRE INSULATION	
ABBREVIATIONS	COLOR
BK	BLACK
BR	BROWN
RD	RED
YL	YELLOW
GN	GREEN
BU	BLUE
VI	VIOLET
GY	GRAY
WT	WHITE
PK	PINK

# 4 SYMBOLS



ENTIRE COMPONENT SHOWN




PART OF A COMPONENT SHOWN



COMPONENT WITH SCREW TERMINALS




SOLID STATE (INCLUDES ONLY ELECTRONIC PARTS)



.5 BU  
.5 BU

CONNECTOR ON COMPONENT LEAD (PIGTAIL)




.8 GN


CONNECTOR ATTACHED TO COMPONENT







COMPONENT CASE IS DIRECTLY ATTACHED TO METAL PART OF CAR (GROUNDED)



INDICATES THAT FUSE 5 IS ALWAYS SUPPLIED WITH POWER



INDICATES THAT FUSE 6 IS SUPPLIED WITH POWER WITH THE IGNITION SWITCH IN THE RUN OR START POSITIONS




DIODE CURRENT CAN FLOW ONLY IN THE DIRECTION OF THE ARROW


CIRCUIT REFERENCE - A WIRE WHICH CONNECTS TO ANOTHER CIRCUIT




ACTIVE CHECK CONTROL



**ONE POLE,  
TWO POSITION  
SWITCH**




**SWITCHES THAT  
MOVE TOGETHER**  
  
DASHED LINE SHOWS  
A MECHANICAL  
CONNECTION  
BETWEEN SWITCHES




**TWO CONNECTIONS  
(PINS) IN THE SAME  
CONNECTOR**

DASHED LINE SHOWS  
PARTS OF THE  
SAME CONNECTOR





**WHEN COIL IS  
ENERGIZED, SWITCH  
IS PULLED CLOSED**

**RELAY SHOWN  
WITH NO  
CURRENT  
FLOWING  
THROUGH  
COIL**






**RELAY SHOWN  
WITH RESISTOR  
ACROSS COIL**  
  
RESISTOR ACROSS COIL  
IS FOR NOISE  
SUPPRESSION

**RELAY SHOWN  
WITH RESISTOR  
ACROSS COIL**



CURRENT PATH  
IS CONTINUED  
AS LABELED.  
THE ARROW SHOWS  
DIRECTION OF CURRENT  
FLOW AND IS REPEATED  
WHERE CURRENT  
PATH CONTINUES.



**LIGHT  
EMITTING  
DIODE**

**OTHER CIRCUITS ALSO GROUNDED  
AT G102 THROUGH S101, BUT ARE  
NOT SHOWN. REFER TO GROUND  
DISTRIBUTION FOR DETAILS.**

## 6 SYSTEMATIC TROUBLESHOOTING

### TROUBLESHOOTING PROCEDURE

#### 1. Verify the Problem

Operate the problem circuit to check the accuracy of the complaint. Note the symptoms of the inoperative circuit.

#### 2. Analyze the Problem

Refer to the schematic of the problem circuit in the ETM. Determine how the circuit is supposed to work by tracing the current path(s) from the power feed through the circuit components to ground. Then based on the symptoms you noted in step 1 and your understanding of circuit operation, identify one or more possible causes of the problem.

#### 3. Isolate the Problem

Make circuit tests to prove or disprove the preliminary diagnosis made in step 2. Keep in mind that a logical simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points which are easily accessible.

#### 4. Repair the Problem

Once the specific problem is identified, make the repair using the proper tools and safe procedures.

#### 5. Check the Problem

Operate the circuit to check for satisfactory circuit operation. Good repair practice calls for rechecking all circuits you have worked on.

### TROUBLESHOOTING TOOLS


Isolating the problem (Step 3 of TROUBLESHOOTING PROCEDURES) requires the use of a **voltmeter** and/or **ohmmeter**. A voltmeter measures voltage at selected points in a circuit. An ohmmeter measures a circuit's resistance to current flow. It has an internal battery that provides current to the circuit under test. Disconnect the car battery when using an ohmmeter because the battery voltage will cause the ohmmeter to give false readings. Also, do not use an ohmmeter on solid-state components. The voltage that the ohmmeter applies to the circuit could damage these components.

### TROUBLESHOOTING TESTS

#### Voltage Test

This test measures voltage in a circuit. By taking measurements at several points (terminals or connectors) along the circuit, you can isolate the problem.

To take a voltage measurement, connect the negative lead of the voltmeter to the battery's negative terminal or other known good ground. Then connect the positive lead of the voltmeter to the point you want to test. The voltmeter will measure the voltage present at that point in the circuit.




Voltage Test



Voltage Drop Test

Wires, connectors, and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.


To test for voltage drop, connect the voltmeter leads to connectors at either end of the circuit's suspected problem area. The positive lead should be connected to the connector closest to the power source. The voltmeter will show the voltage drop between these two points.



Voltage Drop Test

Continuity Test

To perform a continuity test, first disconnect the car battery. Then adjust the ohmmeter to read zero while holding the leads together. Connect the ohmmeter leads to connector or terminals at either end of the circuit's suspected problem area. The ohmmeter will show the resistance across that part of the circuit.




Continuity Test

Short Test Using Voltmeter

Remove the blown fuse and disconnect the load. Connect the voltmeter leads to the fuse terminals. The positive lead should be connected to the terminal closest to the power source.

Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the voltmeter reading. If the voltmeter registers a reading, there is a short to ground in the wiring. Somewhere in the area of the harness being moved, the wire insulation is worn away and the circuit is grounding.




Short Test Using Voltmeter

## 8 SYSTEMATIC TROUBLESHOOTING


### Short Test Using Ohmmeter

Disconnect the battery. Adjust the ohmmeter to read zero while holding the leads together. Remove the blown fuse and disconnect the load. Connect one lead of the ohmmeter to the fuse terminal that is closest to the load. Connect the other lead to a known good ground.

Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the ohmmeter reading. Low or no resistance indicates a short to ground in the wiring. Infinitely high resistance indicates no short.




Short Test Using Ohmmeter



DIAGNOSTIC CONNECTOR

PIN	WIRE SIZE	WIRE COLOR	CIRCUIT AND COMPONENT CONNECTED
1	1.5	BR	Ground Distribution G101
4	.5	BR/VI	Gauges/Warning Indicators, Coolant Temperature Sender.
5	.5	WT/GN	Fuel Control, Injector Control Module (Fuel Rate)
7	.5	WT/BU	Service Interval Indicator, Service Interval Processor (Reset).
11	2.5	BK/YL	Start, Start Signal.
12	.75	BU	Charge System, Alternator.
13	.75	BK	Ignition, Ignition Coil.
14	2.5	RD	Charge System, Alternator.
15	1.5	GN/YL	Idle Speed Control, Idle Speed Control Unit.

# 102 POWER DISTRIBUTION BOX



C101  
**Figure 1 - Behind Left Front Shock Tower**

FUSE NO.	SIZE/ COLOR	CIRCUIT NAME
1	7.5A (BR)	Headlights (also fuses 2, 13, 16).
2	7.5A (BR)	Headlights (also fuses 1, 13, 14).
3	15A (LT BLU)	Auxiliary Fan (also fuse 18).
4	15A (LT BU)	Lights: Turn/Hazard Warning (also fuse 24).
5	25A (WT)	Wiper/Washer.
6	7.5A (BR)	Stoplights.
7	15A (LT BU)	Horn.
8	25A (WT)	Lights: Dash Rear Defogger; Seatbelt Warning (also fuse 10); Speedometer/Indicators (also fuse 12).
9	15A (LT BU)	Idle Speed Control/Vacuum Advance; Backup Lights.
10	7.5A (BR)	Seatbelt Warning (also fuse 8); Service Interval Indicator (also fuse 24); Tachometer/Fuel Economy Gauges (also fuse 24); Gauges/Indicators; Brake Warning System.
11	15A (LT BU)	Fuel Delivery.
12	7.5A (BR)	Radio (also fuse 21); Speedometer/Indicators (also fuse 8).
13	7.5A (BR)	Headlights (also fuses 1, 2, 14).
14	7.5A (BR)	Headlights (also fuses 1, 2, 13).
15		Not Used.
16		Not Used.
17	15A (LT BU)	Accessory Connector.(Not Used)
18	30A (LT GN)	Auxiliary Fan (also fuses 3, 19).
19	7.5A (BR)	Auxiliary Fan (also fuses 3, 18); Interior Lights (also fuses 21, 22, 27). Power Mirrors.

FUSE NO.	SIZE/ COLOR	CIRCUIT NAME
20	30A (LT GN)	Heater/Air Conditioning (also fuse 28).
21	7.5A (BR)	Auto-Charging Flashlight; Digital Clock; Glove Box Light; Ignition Key Warning; Interior Lights (also fuses 14, 22, 27); Radio (also fuses 12); Trunk Light.
22	7.5A (BR)	Interior Lights (also fuses 19, 21, 27); Lights: Front Park/Tail; Lights: Front Side Marker.
23	7.5A (BR)	Lights: Dash; Lights: Front Park/Tail; Lights: Front Side Marker; Lights: Rear Marker/License.
24	15A (LT BU)	Lights: Turn/Hazard Warning (also fuse 4); Tachometer/Fuel Economy Gauges (also fuse 10); Service Interval Indicator (also fuse 10).
25	25A (WT)	Not Used.
26	25A (WT)	Not Used.
27	25A (WT)	Interior Lights (also fuses 19, 21, 22). Central Locking.
28	25A (WT)	Cigar Lighter; Power Antenna.
29	7.5A (BR)	Fog Lights.
30	7.5A (BR)	Fog Lights.

# 104 POWER DISTRIBUTION

(For Component Locations See Page 201)

