


V000130

Fig 205.

- d Take out the 2nd reduction sun gear **205-A**.
- e Lift and remove the gearbox top section **205-B**.


3 Remove ring gear.

- a Remove the O-ring seal **206-A** from the ring gear.
- b Take out the 2nd reduction planet gear **206-B**



V000140

Fig 206.



V000150


Fig 207.

- c Remove the ring gear **207-C**
- d Remove the O-ring seal from the under side of ring gear.

Note: In order to proceed with the gearbox disassembly, it is now necessary to remove it from the machine and take it to a properly equipped workshop.


4 Remove gearbox housing.

- a Fit socket box wrench **208-A** and nut adapter tools **208B** see **Service Tools**, onto the ring nut **208-C** and using a torque multiplier (1:25) ⇒ [Fig 209](#). ([E-165](#)), unscrew the ring nut.



V000160


Fig 208.



V000170

Fig 209.


- b Remove the ring nut **210-A**



V000180

Fig 210.


- c Attach a puller/extractor **211-A** to the gearbox housing **211-B** and apply pressure to separate the pinion shaft and lower bearing from the gearbox housing. After separation, use suitable lifting tackle to raise and remove the gearbox housing.



V000190

Fig 211.


- 5 Separate pinion shaft from bearing.
 - a Use suitable lifting tackle to raise and suspend the pinion shaft and bearing **212-A** and fit the collar **212-B** of separation tool, **see Service Tools**, over the pinion and up against the bearing.
 - b Position the tubular spacer **212-C** of separation tool, **see Service Tools**, beneath the pinion shaft and bearing and lower the pinion shaft and bearing complete with collar onto the spacer.
 - c Use a press to separate the pinion shaft from the bearing.



V000200

Fig 212.


- Remove the bearing **213-A** from the gearbox housing.



V000210

Fig 213.

- Use stopper **214-A**, see *Service Tools* to remove the ring seal from the gearbox housing.



V000220

Fig 214.

Gearbox Inspection

Before assembling the gear box make sure that a thorough inspection of all the components is carried out. Remember that although a failed component may be easy to identify, the cause may be less easy to trace. It is also possible that a failed component may have caused damage to other areas of the gearbox.

Components that are subject to general wear and tear are the following:

- Gears
- Pinion shaft
- Bearings
- Seals

- 1 Carefully clean all components using a suitable degreasing agent.
- 2 Carefully inspect all gears, bearings and shafts for signs of excessive wear or damage. If wear or damage is evident, components must be renewed.
- 3 In the case of damaged gears, for example a planetary gear, do not proceed to replace the individual gears but the entire assembly.