




6610.2 REMOTE CONTROL ZV/DWA

Z3





01/01

6610.2 00

2001


7100.0 COMPONENT LOCATION VIEWS



A35y
BOARD COMPUTER
(BC – LOW)


S220
AIR CONDITIONING/
RECIRCULATING
SWITCH ASSEMBLY

X10245
X18349



X10010
GROUND

X13004
GROUND



K46
HIGH BEAM LIGHT
RELAY



K6301w
FUEL PUMP RELAY

N17
CRASH CONTROL
MODULE

P97
AUXILIARY FUSE
BOX

X322
X1588


COMPONENT LOCATION VIEWS



M6510
STARTER

X6510
CABLE SOCKET
STARTER, TERMINAL 50


X6512
CABLE SOCKET
STARTER, TERMINAL 30



X165
GROUND

X6454
GROUND

X6455
GROUND





K25
RIGHT PARK
LIGHT/LICENSE
PLATE LIGHT
RELAY

K26
LEFT PARK LIGHT
RELAY

K70
CENTRAL LOCKING
LUGGAGE
COMPARTMENT
LID MOTOR RELAY
(ZV)


COMPONENT LOCATION VIEWS



G19
BATTERY SAFETY
TERMINAL

P99
FUSE HOLDER

X10467



E17
RIGHT REAR LIGHT
ASSEMBLY

G1
BATTERY

X318



H55z
REAR LEFT MID-
HIGH RANGE
SPEAKER

X537